



**Personalized Custom  
Sports Products**

## How to apply your protective laminate over your stick wrap

**Note:** Before you begin, carefully read all the installation instructions to make sure you fully understand the process so you get the best results possible. It is very important to take your time and don't rush when applying your laminate. The entire process should only take about 10-15 minutes. The more careful and prepared you are the better it will apply.

**Step 1:** To start, wipe your stick clean and remove all glue or tape that may interfere with the coating. Before applying cut the laminate to the correct length. Start by holding the bottom of the strip even with the bottom of the shaft. (remove the knob) Mark it where the shaft meets the basket and cut to that length.

**Step 2:** Now begin peeling your laminate from the backing. The back is the shiny side. (Note: it is tricky but it does peel off). Only peel it about 6-8 inches to prevent the bottom portion from sticking to anything before you're ready.

**Step 3:** With the front of the stick facing toward you press only the very top of the wrap against the stick so that the front of the stick is lined-up exactly in the centre of the laminate strip. If you miss your mark the first time you can peel it off and try again. It is very important to get the top right as it will keep straight as you move down. Once you have it, press it firmly and slide your thumb down 2-3 inches.

**Step 4:** Peel the rest of the backing off, keeping it lined up down the front face of the stick while pressing it in firmly. You will find that sliding your thumb along the strip with pressure helps to remove any imperfections and bubbles.

**Step 5:** When you are satisfied with the position on the front face of the stick use your thumb to firmly rub the front of the wrap along the entire front side.

**Step 6:** Go back to the top of the stick and work the right side. Press firmly and apply the right side to the top of the stick, using your thumb to rub from the front of the stick around the curved edge and over the right side. You will find that this allows any air to escape and tightens the front and side of the laminate onto the stick. Continue this process inch by inch down the rest of the right side. Remember to start with your thumb on the front, rub firmly around the edge and onto the entire width of the right side.

**Step 7:** Now that the right side is on snugly move back to the top and apply the right back of the wrap. Similar to the last two steps you'll be starting with your thumb on the side and press firmly around the curved edge and smooth the back of the wrap onto the stick. Continue this process inch by inch until you get to the bottom again.

**Step 8:** Perform the same steps with the left side that you did for the right. The wrap will slightly overlap on the back face of stick.

**Step 9:** The overlap will be on the back side. If you feel any edge that will not stick, you can trim it back. Once it is applied, you can go over it a few times rubbing it firmly with any type of plastic instrument. Then apply the seam tape down over the seam to smooth it out.

**Note:** the stick will have a slightly cloudy appearance once the protective laminate is applied.

If you have any problems or questions, or would like information on other products, please contact us at [info@sportswraps.ca](mailto:info@sportswraps.ca)

*Thanks*



[www.sportswraps.ca](http://www.sportswraps.ca)